



# GCP-30 Series

## Genset Control Package Mains & Generator Protection & Control

### APPLICATIONS

The GCP-30 Series genset control is designed to provide total control for multiple, medium to large sized applications.

A network of the compact, versatile GCP-30 controls is capable of controlling up to **14** gensets with automatic sequencing. Load management features include automatic base loading/peak shaving, import/export control and emergency power/back up power generation.

The GCP-31 has logic for one circuit breaker and the GCP-32 has logic for two circuit breakers including open/closed transition.

Fully integrated communication to engine ECUs including [via CAN bus] standard SAE J1939, Deutz EMR, Scania S6, Volvo EMS2, mtu ADEC, mtu MDEC; [via RS232] Caterpillar CCM to EMCP-II, and ECM.

### DESCRIPTION

#### Features

- True RMS 8x voltage (generator/busbar/mains)
- True RMS 4x current (generator/mains)
- Start/stop sequence for Diesel/Gas engines
- Engine pre-glow or purge control
- Battery voltage monitoring
- Speed control with overspeed monitoring
- Idle speed mode operation
- kWh/operation hours/start/maintenance counter
- Load dependent start/stop for up to **14 generators**
- Configurable trip/control set points
- Configurable delays for each protection/alarm
- Magnetic/switching Pickup input
- 16 configurable discrete alarm inputs
- 7 configurable/programmable relays
- Two-line LC display
- Synchroscope
- Push-buttons for direct control
- CAN bus communication
- Multi-level password protection
- Language manager (English/German switchable)

### DESCRIPTION (continued)

#### Protection ANSI #

- 3/4-line measurements
- Mains**
  - Over-/undervoltage (59/27)
  - Over-/underfrequency (81O/U)
  - Phase/vector shift (78)
- Generator**
  - Over-/undervoltage (59/27)
  - Over-/underfrequency (81O/U)
  - Overload (32)
  - Reverse/reduced power (32R/F)
  - Unbalanced load (46)
  - Time-overcurrent (TOC) (50)

#### Controller (all versions)

- Speed/frequency/real power
- Voltage/power factor cosphi
- Mains import/export power
- Load/var sharing for up to **14 generators**

#### Controller (GCP-31)

- Synchronizer for 1 CB
- Isolated operation
  - Softloading
  - Mains parallel operation

#### Controller (GCP-32)

- Synchronizer for 2 CB
- same as GCP-31 plus following
  - Open transition (break-before-make)
  - Closed transition (make-before-break)

#### Special (Version dependent)

- 2 configurable analog outputs (0/4 to 20 mA)
- Generator real power setpoint via 0/4 to 20 mA
- Mains import/export power via 0/4 to 20 mA
- Discrete outputs raise/lower for n/f/V/P/Q
- Analog outputs raise/lower for n/f/V/P/Q
- PWM outputs raise/lower for n/f/P
- 7 conf. analog measuring inputs (0/4 to 20 mA, Pt100, VDO)
- Coupling to LS 4 (GCP-31 only; for details see product specification 37167)
- Event recorder with real time clock





- **J1939** (Volvo EMS2, mtu ADEC, Scania S6, Deutz EMR), mtu **MDEC**, and CAT **CCM** (EMCP-II, and ECM) coupling
- AMF auto start/stop
- Complete engine, generator, and mains protection and controller in one unit
- True RMS sensing of generator, busbar and mains voltage as well as generator and mains current
- Synchronization for one/two breakers
- Load management-automatic base load/peak shaving, import/export power control, automatic sequencing
- Load/var sharing for up to **14 generators** incl. auto start/stop
- Counters for kWh, engine starts, operating hours, maintenance call
- Freely configurable discrete and analog alarm inputs
- Freely configurable relay and analog outputs
- Configurable via PC or front panel
- CAN bus based communication
- CE marked
- UL/cUL Listed

# SPECIFICATIONS (for more see manual 37364)

Accuracy .....	Class 1	
Power supply .....	12/24 Vdc (9.5 to 32 Vdc)	
Intrinsic consumption .....	max. 20 W	
Ambient temperature .....	Operation .....	-20 to 70 °C
	Storage .....	-30 to 80 °C
Ambient humidity .....	95 %, non-condensing	
Voltage .....	Rated $\lambda/\Delta$ :	[1] 66/115 Vac or [4] 230/400 Vac
	$V_{ph-ph}$ max. (UL):	[1] 150 Vac or [4] 300 Vac
	Rated $V_{ph-ground}$ :	[1] 150 Vac or [4] 300 Vac
	Rated surge voltage:	[1] 2.5 kV or [4] 4.0 kV
	Setting range (prim.):	0.050 to 65.000 kVAc
Measuring frequency .....	50/60 Hz (40 to 70 Hz)	
Linear measuring range up to .....	$1.3 \times V_{rated}$	
Input resistance .....	[1] 0.21 M $\Omega$ , [4] 0.7 M $\Omega$	
Max. power consumption per path .....	< 0.15 W	
Current (rated values; $I_{rated}$ ) .....	.75 A	
Linear measuring range up to .....	$I_{gen} = 3.0 \times I_{rated}$	
	$I_{mains} = 1.5 \times I_{rated}$	
Load .....	< 0.15 VA	
Rated short-time current (1 s) .....	$10 \times I_{rated}$	
Discrete inputs .....	isolated	
Input range .....	12/24 Vdc (6 to 32 Vdc)	
Input resistance .....	approx. 6.8 k $\Omega$	
Analog inputs .....	freely scaleable	
Type .....	0/4 to 20 mA, Pt100, VDO	
Resolution .....	10 Bit	

Relay outputs .....	potential free	
Contact material .....	AgCdO	
Load (GP) .....	2.00 Aac@250 Vac	
	2.00 Adc@24 Vdc / 0.36 Adc@125 Vdc / 0.18 Adc@250 Vdc	
Pilot duty (PD) .....	1.00 Aac@250 Vdc	
	1.00 Adc@24 Vdc / 0.22 Adc@125 Vdc / 0.10 Adc@250 Vdc	
Analog outputs .....	isolated	
Type .....	0/4 to 20 mA, freely scaleable	
Resolution .....	.8/12 Bit (depending on model)	
Max. load 0/4 to 20 mA .....	500 $\Omega$	
Insulating voltage .....	1,500 Vdc	
Housing .....	Type APRANORM DIN 43 700	
Dimensions .....	144x144x118 mm	
Front cutout .....	138[+1.0]x138[+1.0] mm	
Connection .....	screw/plug terminals depending on connector 1.5 mm <sup>2</sup> or 2.5 mm <sup>2</sup>	
Front .....	insulating surface	
Protection system .....	with correct installation	
	Front .....	IP42
		(sealed IP54; gasket kit = P/N 8923-1039)
	Back .....	IP21
Weight .....	depending on version, approx. 1,000 g	
Disturbance test (CE) .....	tested according to applicable EN guidelines	
Listings .....	UL/cUL listed (File No.: E231544)	


## DIMENSIONS




2002-11-21 | GCP30-AMG2 Dimensions g2ww-4702-ab.skf

## APPLICATIONS

Typical application for the GCP-32 (GCP-31 same but without MCB)



# WIRING DIAGRAM (example: GCP-32/XPQ+SC10; for more see manual 37364)



The socket for the PC configuration is situated on the side of the unit. This is where the DPC has to be plugged in.

GCP-32/XPQ+SC10

Subject to technical modifications.

Starting Release version 4.2006

2007-01-18 | GCP30 Wiring Diagram g2ww-0307-ap-04

# FEATURES OVERVIEW

**International**  
 Woodward  
 PO Box 1519  
 Fort Collins CO, USA  
 80522-1519  
 1000 East Drake Road  
 Fort Collins CO 80525  
 Ph: +1 (970) 482-5811  
 Fax: +1 (970) 498-3058

**Europe**  
 Woodward GmbH  
 Handwerkstrasse 29  
 70565 Stuttgart, Germany  
 Ph: +49 (0) 711 789 54-0  
 Fax: +49 (0) 711 789 54-100

**Distributors & Service**  
 Woodward has an international network of distributors and service facilities. For your nearest representative, call the Fort Collins plant or see the Worldwide Directory on our website.

[www.woodward.com/power](http://www.woodward.com/power)

For more information contact:

Subject to technical modifications.

This document is distributed for informational purposes only. It is not to be construed as creating or becoming part of any Woodward Governor Company contractual or warranty obligation unless expressly stated in a written sales contract.

We appreciate your comments about the content of our publications. Please send comments including the document number below to [stgt-doc@woodward.com](mailto:stgt-doc@woodward.com)

© Woodward

All Rights Reserved

03240G - 2007/2/Stuttgart

GCP-30 Series Genset Control	GCP-31					GCP-32					
	Package	BPC	XPD	XPO	XPO+SB03	XPO+SC10	BPC	XPD	XPO	XPO+SB03	XPO+SC10
<b>Control</b>											
Breaker control logic	1	1	1	1	1	2	2	2	2	2	2
Synchronization	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Isolated single-unit operation	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
AMF (auto mains failure operation)		✓ #1	✓ #1	✓ #1	✓ #1	✓	✓	✓	✓	✓	✓
Stand-by operation	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Peak load op. (auto start/stop)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Mains parallel operation	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Open transition (break-before-make)						✓	✓	✓	✓	✓	✓
Closed transition (make-before-break)						✓	✓	✓	✓	✓	✓
Softloading	✓ #2	✓ #2	✓ #2	✓ #2	✓ #2	✓	✓	✓	✓	✓	✓
<b>Accessories</b>											
Start/stop logic for Diesel/Gas engines	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
kWh counter	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Operating hours/start/maintenance counter	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Configuration via PC #3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Event recorder, real time clock		50	50	50	50		50	50	50	50	50
Language manager (English/German)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
<b>Protection</b>											
Generator: voltage/frequency	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Mains: volt./freq./phase shift	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Generator: overload/unbalanced load	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Generator: reverse/reduced power	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Generator: time-overcurrent (TOC)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
<b>Controller</b>											
Discrete raise/lower: n/f & P #4	✓ #5	✓	✓ #5	✓ #5	✓ #5	✓ #5	✓	✓ #5	✓ #5	✓ #5	✓ #5
Discrete raise/lower: V & Q #4	✓ #5	✓	✓ #5	✓ #5	✓ #5	✓ #5	✓	✓ #5	✓ #5	✓ #5	✓ #5
Analog raise/lower: n/f & P #4 #5	✓		✓	✓	✓	✓		✓	✓	✓	✓
Analog raise/lower: V & Q #4 #5	✓		✓	✓	✓	✓		✓	✓	✓	✓
PWM raise/lower: n/f & P #4 #5	✓		✓	✓	✓	✓		✓	✓	✓	✓
Mains import/export power via 20 mA		✓	✓	✓	✓		✓	✓	✓	✓	✓
Mains import/export power control	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Load-dependent start/stop	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Active power setpoint 0/4 to 20 mA #6	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Load/var sharing for 14 generators	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
<b>I/O's</b>											
Magnetic/switching Pickup	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Discrete alarm inputs (configurable)	16	16	16	16	16	16	16	16	16	16	16
Relay outputs (configurable)	7	7	7	7	7	7	7	7	7	7	7
Analog inputs (configurable) #6		7	7	7	7		7	7	7	7	7
Analog outputs 0/4 to 20 mA (configurable)		2	2	2	2		2	2	2	2	2
External operation mode selection via DI		✓	✓	✓	✓		✓	✓	✓	✓	✓
CAN bus comm., Guidance level #7	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
CAN bus comm., Engine level #8					✓						✓
RS-232 comm., Engine level #9				✓						✓	
LS 4 - Circuit Breaker Control #10		✓	✓	✓	✓						
<b>Listings/Approvals</b>											
CE Marked	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
UL/cUL Listed	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
<b>Part numbers P/N</b>											
Measuring inputs 100 Vac, .5 A (8440-	-1609	-1554	-1558	-1562	-1560	-1613	-1570	-1574	-1578	-1576	
Measuring inputs 400 Vac, .5 A (8440-	-1610	-1555	-1559	-1563	-1561	-1614	-1571	-1575	-1579	-1577	

#1 External unit LS 4 necessary  
 #2 In isolated parallel operation with min. 2 gensets in parallel  
 #3 Cable incl. software necessary (DPC; P/N 5417-557)  
 #4 n = speed; f = frequency; V = voltage, P = real power; Q = reactive power  
 #5 +/-20 mA and +/-10 Vdc and PWM signal (type and range configurable); bias/discrete setpoint via relay manager  
 #6 [T1]-[T3] = 0/4 to 20 mA, [T4]/[T5] = Pt100, [T6] = VDO 0 to 180ohm, [T7] = VDO 0 to 380ohm; function of 20 mA inputs is configurable between alarm input, remote setpoint value for generator real power, mains import/export real power measuring value; others upon request  
 #7 Remote monitoring, control, configuration (GW 4 could be used for several interfaces; refer to product specs 37170 / manual 37360)  
 #8 CAN bus connection to IKD1, mtu MDEC, mtu ADEC, Volvo EMS2, Scania EMS/S6, CAN SAE J1939 and/or ST3 (configurable; refer to manual 37382)  
 #9 RS-232 connection via Caterpillar CCM to Caterpillar EMCP-II, and ECM (configurable; refer to manual 37200)  
 #10 External unit LS 4 (refer to product specs 37167 / manual 37105)